

1975-CO Wiring Diagram, Coin Box Reset and Timer instructions



To Reset Cover: Insert a ball point pen point into the hole in the arm, move arm to the right and down. Cover is now reset and ready to use.

Note: Total movement very little.



Reset Power after changing timer dip switches. Example shows 1.5 minutes and 3 quarters.

> 120 VOLT / 15 AMP LINE VOLTAGE

Important: Refer to local and Electrical Code information prior to installation.



Universal Valve Compnay Inc 478 Schiller St- Elizabeth NJ 07206 www.universalvalve.com sales@universalvalve.com 800-223-0741

